




HOW TO MEASURE

A - HEAD CIRCUMFERENCE

Using a measuring tape, measure the head circumference at the head’s widest point, just above the eyebrows and the ears.

SHELL SIZE	S		M	L	XL	
A - HEAD CIRCUMFERENCE (CM)	XS 53-54	S 55-56	M 57-58	L 59-60	XL 61-62	XXL 63-64
A - HEAD CIRCUMFERENCE (INCHES)	XS 20.8-21.2	S 21.6-22	M 22.4-22.8	L 23.2-23.6	XL 24-24.4	XXL 24.8-25.2
CROWN PAD - REGULAR (MM)	15	10	10	10	10	8
CROWN PAD (+5 MM)	20		15	15	15	
CHEEK PADS - REGULAR (MM)	35	30	30	20	20	15
CHEEK PADS (+5 MM)	40	25				
TOP PAD - REGULAR (MM)	15					
TOP PAD (+5 MM)	20					

CHEEK PAD

The same cheek pads can be used with all helmet sizes.
Example - Cheek pad size M - Regular size is 30.
If you want a tighter fit, then you can choose size 35 or 40 (all available as optional parts).
If you want a looser fit, then you can choose size 25 or 20 or 15 (all available as optional parts).

CROWN PAD

The crown pad varies depending on the helmet size.
The same crown pad can be used within sizes XS and S, or XL and XXL.
Example - Crown pad size S - Regular size is 10.
If you want a tighter fit, then you can choose the crown pad 15 or 20.
Please check your helmet size before purchasing your crown pad.

MEN'S & WOMEN'S OFF-ROAD HELMET - INTL

2023



HOW TO MEASURE

- 1. Measure the head circumference at the widest part of the head, just above the eyebrows and ears.**

 Size 	 Head Circumference
 XS 	 54-56 cm
 S 	 56-58 cm
 M 	 58-60 cm
 L 	 60-62 cm
 XL 	 62-64 cm
 XXL 	 64-66 cm
 XXXL 	 66-68 cm
 XXXXL 	 68-70 cm
 XXXXXL 	 70-72 cm

SIZE GUIDE - MOTO LEATHER SUITS 1PC & 2PC - MENS

SIZE	44		46		48		50		52		54		56		58		60		62		64		66		68	
A. CHEST (CM)	86	90	90	94	94	98	98	102	102	106	106	110	110	114	114	118	118	122	122	126	126	130	130	134	134	138
B. WAIST (CM)	72	76	76	80	80	84	84	88	88	92	92	96	96	100	100	104	104	108	108	112	112	116	116	120	120	124
C. HIP (CM)	87	91	91	95	95	99	99	103	103	107	107	111	111	115	115	119	119	123	123	127	127	131	131	135	135	139
E. INNER LEG (CM)	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	89	90	91	92	91	92	91	92	91	92
F. OUTER ARM (CM)	54	55	56	57	58	59	60	61	62	63	64	65	65	66	67	68	67	68	68	69	68	69	68	69	68	69
G. HEIGHT (CM)	165	168	169	172	173	176	177	180	181	184	185	188	189	192	192	195	192	195	196	199	196	199	196	199	196	199
A. CHEST (IN)	33 7/8	35 3/8	35 3/8	37	37	38 5/8	38 5/8	40 1/8	40 1/8	41 3/4	41 3/4	43 1/4	43 1/4	44 7/8	44 7/8	46 1/2	46 1/2	48	48	49 5/8	49 5/8	51 1/8	51 1/8	52 3/4	52 3/4	54 3/8
B. WAIST (IN)	28 3/8	29 7/8	29 7/8	31 1/2	31 1/2	33 1/8	33 1/8	34 5/8	34 5/8	36 1/4	36 1/4	37 3/4	37 3/4	39 3/8	39 3/8	41	41	42 1/2	42 1/2	44 1/8	44 1/8	45 5/8	45 5/8	47 1/4	47 1/4	48 7/8
C. HIP (IN)	34 1/4	35 7/8	35 7/8	37 1/2	37 3/8	39	39	40 1/2	40 1/2	42 1/8	42 1/8	43 3/4	43 3/4	45 1/4	45 1/4	46 7/8	46 7/8	48 3/8	48 3/8	50	50	51 5/8	51 5/8	53 1/8	53 1/4	54 3/4
E. INNER LEG (IN)	29 1/2	29 7/8	30 1/4	30 3/4	31 1/8	31 1/2	31 7/8	32 1/4	32 5/8	33 1/8	33 1/2	33 7/8	34 1/4	34 5/8	35	35 3/8	35	35 3/8	35 7/8	36 2/8	35 7/8	36 1/4	35 7/8	36 1/4	35 7/8	36 1/4
F. OUTER ARM (IN)	21 1/4	21 5/8	22	22 1/2	22 7/8	23 1/4	23 5/8	24	24 3/8	24 3/4	25 1/4	25 1/2	25 5/8	26	26 3/8	26 3/4	26 3/4	26 3/4	26 3/4	27 1/8	26 3/4	27 1/8	26 3/4	27 1/8	26 3/4	27 1/8
G. HEIGHT (IN)	65	66 1/8	66 1/2	67 3/4	68 1/8	69 1/4	69 3/4	70 7/8	71 1/4	72 1/2	72 7/8	74	74 3/8	75 5/8	75 5/8	76 3/4	75 5/8	76 3/4	77 1/8	78 3/8	77 1/8	78 3/8	77 1/8	78 3/8	77 1/8	78 3/8

HOW TO MEASURE

A. CHEST

Measure around the fullest part, under the armpits, keeping the tape horizontal.

B. WAIST

Measure around the natural waist line, inline with the navel, keeping the tape horizontal.

C. HIP

Measure around the fullest part of your hips, about 20cm below waist line, keeping the tape horizontal.

D. THIGH

Measure around the thigh just below the crotch, keeping the tape horizontal.

E. INNER LEG


Stand against a wall, ask someone else to measure from the crotch to the bottom of your leg.

F. OUTER ARM

Measure from shoulder (Humerus) to wrist.

G. HEIGHT

Stand against a wall, ask someone else to measure from the floor to the top of your head, keeping the tape vertical.



SIZE GUIDE - MOTO LEATHER JACKET - MENS

SIZE	44		46		48		50		52		54		56		58		60		62		64		66		68	
A. CHEST (CM)	86	90	90	94	94	98	98	102	102	106	110	110	114	114	118	118	122	122	126	126	130	130	134	134	138	138
B. WAIST (CM)	72	76	76	80	80	84	84	88	88	92	96	96	100	100	104	104	108	108	112	112	116	116	120	120	124	124
F. OUTER ARM (CM)	54	55	56	57	58	59	60	61	62	63	64	65	65	66	67	68	67	68	68	69	68	69	68	69	68	69
G. HEIGHT (CM)	165	168	169	172	173	176	177	180	181	184	185	188	189	192	192	195	192	195	196	199	196	199	196	199	196	199
A. CHEST (IN)	33 7/8	35 3/8	35 3/8	37	37	38 5/8	38 5/8	40 1/8	40 1/8	41 3/4	41 3/4	43 1/4	43 1/4	44 7/8	44 7/8	46 1/2	46 1/2	48	48	49 5/8	49 5/8	51 1/8	51 1/8	52 3/4	52 3/4	54 3/8
B. WAIST (IN)	28 3/8	29 7/8	29 7/8	31 1/2	31 1/2	33 1/8	33 1/8	34 5/8	34 5/8	36 1/4	36 1/4	37 3/4	37 3/4	39 3/8	39 3/8	41	41	42 1/2	42 1/2	44 1/8	44 1/8	45 5/8	45 5/8	47 1/4	47 1/4	48 7/8
F. OUTER ARM (IN)	21 1/4	21 5/8	22	22 1/2	22 7/8	23 1/4	23 5/8	24	24 3/8	24 3/4	25 1/4	25 1/2	25 5/8	26	26 3/8	26 3/4	26 3/8	26 3/4	26 3/4	27 1/8	26 3/4	27 1/8	26 3/4	27 1/8	26 3/4	27 1/8
G. HEIGHT (IN)	65	66 1/8	66 1/2	67 3/4	68 1/8	69 1/4	69 3/4	70 7/8	71 1/4	72 1/2	72 7/8	74	74 3/8	75 5/8	75 5/8	76 3/4	75 5/8	76 3/4	77 1/8	78 3/8	77 1/8	78 3/8	77 1/8	78 3/8	77 1/8	78 3/8

HOW TO MEASURE

A. CHEST

Measure around the fullest part, under the armpits, keeping the tape horizontal.

B. WAIST

Measure around the natural waist line, inline with the navel, keeping the tape horizontal.

C. HIP

Measure around the fullest part of your hips, about 20cm below waist line, keeping the tape horizontal.

D. THIGH

Measure around the thigh just below the crotch, keeping the tape horizontal.

E. INNER LEG


Stand against a wall, ask someone else to measure from the crotch to the bottom of your leg.


F. OUTER ARM

Measure from shoulder (Humerus) to wrist.

G. HEIGHT

Stand against a wall, ask someone else to measure from the floor to the top of your head, keeping the tape vertical.





HOW TO MEASURE

A Hand Circumference:
Wrap a measuring tape around your hand behind the knuckles, not including the thumb, keeping the tape snug. Measure both left and right hands and use the larger of the two measurements.

INTERNATIONAL SIZE	XS	S	M	L	XL	XXL	3XL
MEN’S HAND CIRCUMFERENCE (INCHES)		7½ - 8	8 - 8½	8½ - 9	9 - 9½	9½ - 10	10 - 11
MEN’S HAND CIRCUMFERENCE (CM)		17.8 - 20.3	20.3 - 21.6	21.6 - 22.9	22.9 - 24.1	24.1 - 25.4	25.4 - 27.9
WOMEN’S HAND CIRCUMFERENCE (INCHES)	6½ - 7	7 - 7½	7½ - 8	8 - 8½	8½ - 9		
WOMEN’S HAND CIRCUMFERENCE (CM)	16.5 - 17.8	17.8 - 19	19 - 20.3	20.3 - 21.6	21.6 - 22.9		

SIZE GUIDE - MOTO TEXTILE PANTS - MENS

SIZE	XXS		XS		S		M		L		XL		XXL		3XL		4XL		5XL		6XL	
B.WAIST (CM)	63	69	69	75	75	81	81	87	87	92	92	97	97	102	102	107	107	112	112	117	117	122
C.HIP (CM)	79	84.5	84.5	90	90	95.5	95.5	101	101	106.5	106.5	112	112	117.5	117.5	123	123	128.5	128.5	134	134	139.5
D.THIGH (CM)	48	50.5	50.5	53	53	55.5	55.5	58	58	60.5	60.5	63	63	65.5	65.5	68	68	70.5	70.5	73	73	75.5
E.INNER LEG (CM)	71	73	74	76	77	79	80	82	83	85	86	88	89	91	89	91	91	92	91	92	91	92
G.HEIGHT (CM)	157	162	163	168	169	174	175	179	180	184	185	189	190	194	190	194	195	199	195	199	195	199
B.WAIST (IN)	24 3/4	27 1/8	27 1/8	29 1/2	29 1/2	31 7/8	31 7/8	34 1/4	34 1/4	36 1/4	36 1/4	38 1/4	38 1/4	40 1/8	40 1/8	42 1/8	42 1/8	44 1/8	44 1/8	46	46	48
C.HIP (IN)	31 1/8	33 1/4	33 1/4	35 3/8	35 3/8	37 5/8	37 5/8	39 3/4	39 3/4	41 7/8	41 7/8	44 1/8	44 1/8	46 1/4	46 1/4	48 3/8	48 3/8	50 5/8	50 5/8	52 3/4	52 3/4	54 7/8
D.THIGH (IN)	18 7/8	19 7/8	19 7/8	20 7/8	20 7/8	21 7/8	21 7/8	22 7/8	22 7/8	23 7/8	23 7/8	24 3/4	24 3/4	25 3/4	25 3/4	26 3/4	26 3/4	27 3/4	27 3/4	28 3/4	28 3/4	29 3/4
E.INNER LEG (IN)	28	28 3/4	29 1/8	29 7/8	30 1/4	31 1/8	31 1/2	32 1/4	32 5/8	33 1/2	33 7/8	34 5/8	35	35 7/8	35	35 7/8	35 7/8	36 1/4	35 7/8	36 1/4	35 7/8	36 1/4
G.HEIGHT (IN)	61 3/4	63 3/4	64 1/8	66 1/8	66 1/2	68 1/2	68 7/8	70 1/2	70 7/8	72 1/2	72 7/8	74 3/8	74 3/4	76 3/8	74 3/4	76 3/8	76 3/4	78 3/8	76 3/4	78 3/8	76 3/4	78 3/8

HOW TO MEASURE

A. CHEST

Measure around the fullest part, under the armpits, keeping the tape horizontal.

B. WAIST

Measure around the natural waist line, inline with the navel, keeping the tape horizontal.

C. HIP

Measure around the fullest part of your hips, about 20cm below waist line, keeping the tape horizontal.

D. THIGH

Measure around the thigh just below the crotch, keeping the tape horizontal.

E. INNER LEG


Stand against a wall, ask someone else to measure from the crotch to the bottom of your leg.

F. OUTER ARM

Measure from shoulder (Humerus) to wrist.

G. HEIGHT

Stand against a wall, ask someone else to measure from the floor to the top of your head, keeping the tape vertical.



SIZE GUIDE - RIDING SHOE - US - EUR - JPN

Compare the measurement (in cm) of the longest part of the foot using the table below:
cross reference this value against the **“SHOE INSIDE LENGTH”**.
Then, from this column, check whether the measured length of the foot is greater than the value of the corresponding **“COMFORT SIZE”**.
If you have from same column **“SHOE INSIDE LENGTH”** < measured length of your foot < **“COMFORT SIZE”** you will have the correct shoe size to order.


SHOES INSIDE LENGTH (CM)	24,1	24,5	25	25,4	25,8	26,2	26,7	27,1	27,5	27,9	28,4	28,8	29,2	29,6	30,1	30,5	30,9	31,3	31,8
SHOES INSIDE LENGTH (INCHES)	9,48	9,64	9,84	10	10,15	10,31	10,51	10,66	10,82	10,98	11,18	11,33	11,49	11,65	11,85	12	12,16	12,32	12,51
COMFORT SIZE (CM)	23,3	23,7	24,2	24,6	25	25,4	25,9	26,3	26,7	27,1	27,6	28	28,4	28,8	29,3	29,7	30,1	30,5	31
COMFORT SIZE (INCHES)	9,17	9,33	9,52	9,68	9,84	10	10,19	10,35	10,51	10,66	10,86	11,02	11,18	11,33	11,53	11,69	11,85	12	12,20
US SIZE	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	11½	12	12½	13	13½	14
EUR SIZE	37	37,5	38	38,5	39	40	40,5	41	42	42,5	43	43,5	44	45	45,5	46	47	47,5	48
JPN SIZE	23	23,5	24	24,5	25	25,5	25,5	26	26,5	27	27,5	28	28,5	29,5	29,5	30	30,5	31	31,5

A. SHOES INSIDE LENGTH

Example SIZE 9 (27,5 cm) / (10,82 inches)

B. COMFORT SIZE

Example SIZE 9 (26,7 cm) / (10,51 inches)



SIZE GUIDE - TOURING BOOT - US - EUR - JPN

Compare the measurement (in cm) of the longest part of the foot using the table below:

cross reference this value against the **"SHOE INSIDE LENGTH"**.

Then, from this column, check whether the measured length of the foot is greater than the value of the corresponding **"COMFORT SIZE"**.

If you have from same column **"SHOE INSIDE LENGTH"** < measured length of your foot < **"COMFORT SIZE"** you will have the correct shoe size to order.


SHOES INSIDE LENGTH (CM)	24,0	24,6	25,3	26,0	26,7	27,3	28,0	28,7	29,3	30,0	30,7	31,3	32,0	32,7	33,4
SHOES INSIDE LENGTH (INCHES)	9,44	9,68	9,96	10,23	10,51	10,74	11,02	11,29	11,53	11,81	12,08	12,32	12,59	12,87	13,14
COMFORT SIZE (CM)	23,2	23,8	24,5	25,2	25,9	26,5	27,2	27,9	28,5	29,2	29,9	30,5	31,2	31,9	32,6
COMFORT SIZE (INCHES)	9,13	9,37	9,64	9,92	10,19	10,43	10,70	10,98	11,22	11,49	11,77	12	12,28	12,55	12,83
US SIZE	3½	4	5	6	6 ½	7½	8	9	9½	10½	11½	12	12½	13½	14
EUR SIZE	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50
JPN SIZE	22,5	23	24	25	25,5	26	26,5	27,5	28,5	29,5	30	30,5	31,5	32	33

A. SHOES INSIDE LENGTH

Example SIZE 42 (28,0 cm) / (11,02 inches)

B. COMFORT SIZE

Example SIZE 42 (27,2 cm) / (10,70 inches)




SIZE GUIDE - PERFORMANCE RIDING - SUPERTech R ALL VERSION SMX PLUS v2 ALL VERSION - US - EUR - JPN

Compare the measurement (in cm) of the longest part of the foot using the table below:
cross reference this value against the **“SHOE INSIDE LENGTH”**.
Then, from this column, check whether the measured length of the foot is greater than the value of the corresponding **“COMFORT SIZE”**.
If you have from same column **“SHOE INSIDE LENGTH”** < measured length of your foot < **“COMFORT SIZE”** you will have the correct shoe size to order.

SHOES INSIDE LENGTH (CM)	25,8	26,5	27,2	27,8	28,5	29,2	29,8	30,5	31,2	31,8
SHOES INSIDE LENGTH (INCHES)	10,15	10,43	10,70	10,94	11,22	11,49	11,73	12	12,28	12,51
COMFORT SIZE (CM)	25,0	25,7	26,4	27,0	27,7	28,4	29,0	29,7	30,4	31,0
COMFORT SIZE (INCHES)	9,84	10,11	10,39	10,62	10,90	11,18	11,41	11,69	11,96	12,20
US SIZE	6	6½	7½	8	9	9½	10½	11½	12	12½
EUR SIZE	39	40	41	42	43	44	45	46	47	48
JPN SIZE	25	25,5	26	26,5	27,5	28,5	29,5	30	30,5	31,5

A. SHOES INSIDE LENGTH
Example SIZE 43 (28,5 cm) / (11,22 inches)

B. COMFORT SIZE
Example SIZE 43 (27,7 cm) / (10,90 inches)



SIZE GUIDE - MX BOOT - TECH 10 ALL VERSION - US - EUR - JPN

Compare the measurement (in cm) of the longest part of the foot using the table below:
cross reference this value against the **“SHOE INSIDE LENGTH”**.
Then, from this column, check whether the measured length of the foot is greater than the value of the corresponding **“COMFORT SIZE”**.
If you have from same column **“SHOE INSIDE LENGTH”** < measured length of your foot < **“COMFORT SIZE”** you will have the correct shoe size to order.

SHOES INSIDE LENGTH (CM)	25,8	26,7	27,5	28,4	29,2	30,1	30,9	31,8
SHOES INSIDE LENGTH (INCHES)	10,15	10,51	10,82	11,18	11,49	11,85	12,16	12,51
COMFORT SIZE (CM)	25	25,9	26,7	27,6	28,4	29,3	30,1	31,0
COMFORT SIZE (INCHES)	9,84	10,19	10,51	10,86	11,18	11,53	11,85	12,20
US SIZE	7	8	9	10	11	12	13	14
EUR SIZE	40,5	42	43	44,5	45,5	47	48	49,5
JPN SIZE	25,5	26,5	27,5	29,0	29,5	30,5	31,5	32,5

- A. SHOES INSIDE LENGTH**
Example SIZE 9 (27,5 cm) / (10,82 inches)
- B. COMFORT SIZE**
Example SIZE 9 (26,7 cm) / (10,51 inches)

